

Newel Post Installation Guide Wood Surface (INS-BS)

1. Mark the center of the location where the Newel Post will be installed and drill a ¼" diameter hole on the balcony. Fix the threaded screw in the hole and then fasten the threaded rod in it.
2. Slide the newel post on the threaded rod (threaded rod should go through the post and the transverse aluminium pipe).
3. Place washer and screw tarot onto threaded rod. Tight well.
4. Install cap with caulking.

